


F I G. 1




F I G. 2




F I G. 3




F I G. 4




F I G. 5




F I G. 6



F I G. 7



F I G. 8



F I G. 9

<u> ∫S501</u>

UPDATE TRANSFER RATE, DELAY TIME, AND PACKET LOSS RATE

∽S502

WEIGHT TRANSFER RATE, DELAY TIME, AND PACKET LOSS RATE BEFORE UPDATE; AND ADD THE WEIGHTED VALUES TO THE CURRENT TRANSFER RATE, DELAY TIME, AND PACKET LOSS RATE RESPECTIVELY TO CALCULATE WEIGHTED TRANSFER RATE, WEIGHTED DELAY TIME, AND WEIGHTED PACKET LOSS RATE

END

F I G. 10

START

-S601

WEIGT WEIGHTED TRANSFER RATE, WEIGHTED DELAY TIME, AND WEIGHTED PACKET LOSS RATE WITH VALUES FOR CONVERSION TO METER INDICATIONS RANGING FROM 0 TO 100

-S602

INDICATE CONVERTED VALUES IN METER FROM ON DISPLAY SCREEN

END

F I G. 11

